



K00022 ADAPTER KIT

Installation Instructions

1. The K00022 adapter kit is used for installing a B-0450, B-0600, B-0800, or B-1000 ice machine on a C-950 bin. The bin must be leveled before proceeding to step 2.
2. Installation of adapter (see illustration):
 - A. Remove foam tape from around bin.
 - B. Remove existing ice deflector and install deflectors from kit using existing screws. The two deflectors should be installed end-to-end to make one continuous deflector.
 - C. Apply foam tape to adapters and front and rear bin rail, as shown.
 - D. Locate right-hand and left-hand adapter panels.
 - E. Using the adapter panels as templates, drill four 5/32" diameter holes for each adapter in bin.
 - F. Fasten panels in place with the screws provided in kit.
3. Installation of ice machine:
 - A. Position ice machine on bin.
 - B. Proceed to ice machine installation instructions for electrical and water hook-up and start-up procedure.

Manitowoc Ice, Inc.

2110 South 26 Street, P.O. Box 1720, Manitowoc, WI 54221-1720 USA
8001453

Telephone 920-682-0161, Fax - Sales: 920-683-7589, Service/Parts: 920-683-7585, Other: 920-683-7879

Web Site - www.manitowocice.com

Rev. 04/29/99